



The main central connector is used to connect the main supply air pipe or the main exhaust air pipe to the distribution box. The unused part which diameter is smaller than that of the pipe should be cut off.


- ⊗ Installed in the main slot of the distribution box
- ⊗ Designed for connection of 125 mm, 160 mm and 200 mm pipes
- ⊗ Standard ventilation diameters allows to connect typical round ducts and fittings
- ⊗

MAIN CENTRAL CONNECTOR HEATPEX ARIA





DIMENSIONS					MATERIAL	MASS	CATALOGUE NO.
Height A	Diameter B	Stub end diameter C	Stub end diameter D	Stub end diameter E	PP	0,287	524 109 001
170,4 mm	249 mm	200	160	125			



MAIN CENTRAL CONNECTOR HEATPEX ARIA

*Pressure loss – check data for **Distribution box 10x75** HEATPEX ARIA

